

**SPEEDS AND FEEDS FOR THREADING TOOLS**

<b>MATERIAL</b>	<b>TYPE</b>	<b>SPEED</b>	<b>FEED</b>	<b>FEED</b>
		SURFACE FEET PER MINUTE	Infeed per pass 1st pass	Infeed per pass last pass
<b>PLASTIC</b>	<b>TEFLON</b>	250-400	.015	.001
	<b>NYLON</b>	250-400	.015	.001
	<b>PHENOLIC</b>	250-400	.015	.001
	<b>GLASS FILLED</b>	250-400	.015	.001
<b>MAGNESIUM</b>	<b>AZ, AM, EZ, ZE, HK</b>	100-200	.020	.001
<b>ALUMINUM</b>	<b>2021 THRU 6061</b>	100-200	.020	.001
<b>COPPER</b>		100-200	.010	.001
<b>BRASS</b>		200-300	.010	.001
<b>BRONZE</b>		200-300	.010	.001
<b>CAST IRON</b>		85-140	.015	.0005
<b>STEEL</b>	<b>1005-1029</b>	50-150	.015	.001
	<b>1030-1055</b>	50-150	.015	.001
	<b>1060-1095</b>	50-150	.015	.001
	<b>10L45-10L50</b>	50-150	.015	.001
	<b>12L13-12L15</b>	50-150	.015	.001
	<b>41L30-41L50</b>	50-150	.015	.001
	<b>4140-4150</b>	50-150	.015	.001
	<b>4140 (35 HRc)</b>	50-150	.015	.001
	<b>8617-8622</b>	50-150	.015	.001
	<b>M1-M6</b>	50-150	.015	.001
	<b>H10-H19</b>	50-150	.015	.001
	<b>D2-D7</b>	50-150	.015	.001
	<b>A2-A9, 01-07</b>	50-150	.015	.001
	<b>W1, W2</b>	50-150	.015	.001
<b>TITANIUM</b>	<b>TI-9AI-6V</b>	40-65	.020	.0005
<b>STAINLESS</b>	<b>405-446</b>	65-100	.015	.001
	<b>15-5PH, 16-6PH, 14-4PH</b>	65-100	.015	.001
<b>NICKEL</b>	<b>NICKEL 200-230</b>	40-100	.015	.001

**SINGLE POINT THREADING ROUGHING INFEED DEPTH PER PASS**

<b>THREADS PER INCH</b>	<b>8</b>	<b>10</b>	<b>11</b>	<b>12</b>	<b>13</b>	<b>14</b>	<b>16</b>	<b>18</b>	<b>20</b>	<b>24</b>	<b>28</b>	<b>32</b>	<b>36</b>	<b>40</b>
PASS 1	.0171	.0148	.0148	.0134	.0124	.0114	.0110	.0110	.0099	.0094	.0079	.0083	.0072	.0083
PASS 2	.0283	.0243	.0243	.0219	.0202	.0189	.0179	.0178	.0159	.0150	.0126	.0130	.0113	.0128
PASS 3	.0372	.0318	.0318	.0287	.0264	.0244	.0233	.0231	.0206	.0194	.0163	.0167	.0145	
PASS 4	.0449	.0383	.0383	.0345	.0317	.0293	.0279	.0276	.0246	.0231	.0194			
PASS 5	.0517	.0441	.0441	.0396	.0364	.0337	.0321	.0316	.0282					
PASS 6	.0580	.0494	.0494	.0443	.0407	.0376	.0358							
PASS 7	.0637	.0543	.0543	.0486	.0447	.0413								
PASS 8	.0691	.0588	.0588											
PASS 9	.0742													

*IN MOST CASES  
A FINISH OR SPRING PASS  
IS RECOMMENDED.*

**FORMULA FOR CONVERTING SURFACE FEET PER MINUTE (SFM)  
TO REVOLUTIONS PER MINUTE (RPM)**

$$\frac{RPM = SFM \times 12}{(\pi) \times DIAMETER}$$

NOTE: ALL SPEEDS AND FEEDS LISTED HERE ARE PROVIDED FOR REFERENCE ONLY.